This copy may be copied for maintenance of Richter play equipment. Instructions for wear The equipment must be checked for Proof of correct operation and safety, especially maintenance checks of play equipment the points listed below: Wooden parts Playground..... 1. Check for rot and, if necessary, smooth out Date of installation splinters and round off sharp edges of cracks. Checks depend on the type of equipment. Check that all bolts and screws are tight and Any equipment with moving parts must retighten if necessary. be checked at least twice a year, static equipment at least once a year. Rein chain Intervals for maintenance work and checks 3. Check for wear and tear. generally depend on Structural stability - location - kind of use 4. Examine by rocking the equipment once a - frequency of use year. - possible vandalism For more details see also "General instructions for maintenance of playgrounds". Small "Peter" Horse-cart Order No. 4.24145 1