Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground	Function			
Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static	 Make sure the pump mechanism moves smoothly. Check water hoses for wear and tear; replace if necessary. To do this, loosen lid 			
equipment at least once a year. Intervals for maintenance work and checks generally depend on	bolts (Allen key No. 4) and remove upper part including pump mechanism.3. Clean sieve of pressure reduction valve if soiled.			
- location				
 usage frequency of use possible vandalism For more details see also our general instructions for maintenance of	 Valve and cartridge 4. When replacing the entire valve or the cartridge, pump several times until the automatic shutoff engages (if necessary, shut off the water several times and then turn on again). 			
playgrounds!	Structural stability			
Mushroom Spring Order No. 5.18000 / 5.18001 / 5.18002 / 5.18004 / 5.18005	 Check anchoring to the ground every 12 months, retighten screws and bolts if necessary. Note Prior to the start of the frost period, turn off water supply and remove the mushroom pump. It is necessary to remove at least the upper part. If the housing part is to remain on site, you may order a winter lid (No. 0.97840) from us. If a programmable rinsing device (No. 5.18002) is fitted, the time switch is particularly vulnerable to frost damage as it cannot be drained. Therefore, it is imper- ative the pump be dismantled. Store the pump protected from frost. 		Special notes, e.g. for repairs	
	Repair not carried out, it is still possible to play on equipment			
Foundation anchor Order No. 5.18006	Repair not carried out, equipment is taken out of action			
	All work carried out, everything is in order			
v ∄∞.	Maintenance carried out by: Date			

Spare parts Mushroom Spring Order No. 5.18000-5.18005

F

Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts.**

Order No.	Spare parts	Order No.	Spare parts
0.97833	Self-righting pressure valve (valid until June 2022) <i>please request repair instructions</i> <i>for replacement</i>	0.97837	Seal for hose connection
		0.97839	Replacement old Cartridge (valid until June 2022) to new Cartridge (valid from July 2022)
0.97832	Self-righting pressure valve (valid from July 2022) please request repair instructions for replacement	0.97840	Winter lid
0.97834	Replacement cartridge for self-righting pressure valve please request repair instructions for replacement		
0.97838	Replacement cartridge for self-righting pressure valve <i>please request repair instructions</i> <i>for replacement</i>		
0.97835	Connecting hose with hose protection		
0.97836	Pressure reducer		